

LEE AUTO-DISK RISER



▲ Insert extension tube into body as shown.

◄ Install spacer and tube between the Lee Powder through Expanding Die or Rifle Charging Die and Auto-Disk Powder Measure.

Be sure to install "O" ring between die and riser and measure and riser.

The Lee Auto-Disk Riser allows use of other brands of dies that have extended adjusting screws, providing clearance for the Lee Safety Prime.



LEE PRECISION, INC.
4275 Hwy. U · Hartford WI 53027
www.leeprecision.com

7 34307 90041 0

AD2676